

User Manual

ITCEExtend



AGRA-GPS LTD

Please read this user manual before use & store safely.



Contact us

www.agra-gps.com

jheupel@agragps.com

You may also call us at 587-986-1104

or 780-990-4052

User Manual

ITCEExtend



AGRA-GPS LTD

Please read this user manual before use & store safely.




Contact us

www.agra-gps.com

jheupel@agragps.com

You may also call us at 587-986-1104

or 780-990-4052



Installation

Plug & play install.

Simply plug in the ITCEExtend device between your Starfire ITC receiver and machine. No further set-up is required. Your JD display will now believe it is receiving "SF1" and allow for autosteer. However, signal quality is "WAAS" in North America.

Secure the ITCEExtend at the outside of the cab.

Install Video


Check our Youtube channel "Agra GPS" for a video on how to install your ITCEExtend device.

<https://youtu.be/4VsxGJGFxzQ>

Warranty

1 year parts warranty.

30-day money-back guarantee.



Installation

Plug & play install.

Simply plug in the ITCEExtend device between your Starfire ITC receiver and machine. No further set-up is required. Your JD display will now believe it is receiving "SF1" and allow for autosteer. However, signal quality is "WAAS" in North America.

Secure the ITCEExtend at the outside of the cab.

Install Video

Check our Youtube channel "Agra GPS" for a video on how to install your ITCEExtend device.

<https://youtu.be/4VsxGJGFxzQ>

Warranty

1 year parts warranty.

30-day money-back guarantee.

